





CALIBRATION INSTRUCTIONS

Alpha® Brewer | Brew by Volume


Model: ALP3GT15A826




- 1 Turn the brewer OFF by pressing the yellow ON/OFF button.




- 2 Enter Programming Mode Press and hold BREW button (green) and then press and release ON/OFF button (yellow). Wait until ENTER CODE is displayed.



- 3 Enter the Access Code The default code set at the factory is 1-2-3-4.



- 4 Brew by Volume Press the right arrow 1 time to access the Brew by Volume settings.

Brew by Volume (Factory set to 60 oz.) Press  to select. Display will now show Push START To Begin. Press the BREW button then hot water starts running, when desired volume is reached press BREW button again to stop the flow. Now the volume is set.







CALIBRATION INSTRUCTIONS

Alpha® Brewer | Temperature Settings


Model: ALP3GT15A826



- 1 Turn the brewer OFF by pressing the yellow ON/OFF button.



- 2 Enter Programming Mode Press and hold BREW button (green) and then press and release ON/OFF button (yellow). Wait until ENTER CODE is displayed.



- 3 Enter the Access Code The default code set at the factory is 1-2-3-4.



- 4 Temperature Press the right arrow 3 times to access the temperature settings.

Temperature (Factory set to 202°F) Press **●** to Select. Press < or > to move to desired temperature and then **●** to set. Temperature is programmable from 170°F to 206°F, in 2-degree increments.