




Brewing Instructions



G4GEMXSIFTR10A3026
Single G4GemX 1.5 Gallon Brewer
IntelliFresh® and FreshTrac® Technology



How to Clear Dispenser Lockout Error

Dispenser lockout will appear and brewing will be disabled if:

- There is no dispenser on the brewer
- Liquid is in the dispenser
- The dispenser is cold*

* To quickly heat dispenser, fill with 12 oz. of hot water and allow dispenser to sit for 30 seconds, then discard.

1. Dispenser Lockout.

If dispenser lockout appears on the screen and brewing is disabled.



2. Position Dispenser

Place on brewer, lights will flash green.

3. Prepare Brew Basket

Insert a new paper filter into brew basket.

i **IMPORTANT** - Verify that contact has been made between the dispenser and brewer.



4. Select the Coffee Type

Regular or Decaf.

5. Determine Your Brew Size

Small or Large.

Large Brew



6. Large Brew

Pour three (3) packages of coffee into filter. Level grounds.



7. Insert Brew Basket

Place brew basket into brew rails. Slide back until it stops.



8. Begin Brewing

Select "REGULAR" or "DECAF", then select "BREW 3 BAGS".



BREW BASKET LOCKOUT - Locking pin holds the basket in place during the brew cycle until brewing is complete.

IMPORTANT - During brew cycle, basket will be locked in position and unable to be removed until brew is complete.

BREW LEVEL- Indicated by flashing GREEN lights on front of the dispenser during brew cycle.

BREW COMPLETION - Indicated by solid GREEN lights on front of the dispenser.



9. Brewing is Complete

Remove brew basket. Discard paper coffee filter and used coffee grounds.



10. Transfer Dispenser to Stand

Turn ON the remote stand. Place dispenser onto stand. Slide back ensuring connection. Freshness quality timer will remain accurate when dispenser is properly placed on remote stand.

IMPORTANT - Verify that contact has been made between the dispenser and brewer.

Small Brew



6. Small Brew

Pour one (1) package of coffee into filter. Level grounds.



7. Insert Brew Basket

Place brew basket into brew rails. Slide back until it stops.



8. Begin Brewing

Select "REGULAR" or "DECAF", then select "BREW 1 BAG"



BREW BASKET LOCKOUT - Locking pin holds the basket in place during the brew cycle until brewing is complete.

IMPORTANT - During brew cycle, basket will be locked in position and unable to be removed until brew is complete.

BREW LEVEL- Indicated by flashing GREEN lights on front of the dispenser during brew cycle.

BREW COMPLETION - Indicated by solid GREEN lights on front of the dispenser.



9. Brewing is Complete

Remove brew basket. Discard paper coffee filter and used coffee grounds.



10. Transfer Dispenser to Stand

Turn ON the remote stand. Place dispenser onto stand. Slide back ensuring connection. Freshness quality timer will remain accurate when dispenser is properly placed on remote stand.

IMPORTANT - Verify that contact has been made between the dispenser and brewer.

Coffee Freshness Indicator



 **Fresh**

GREEN - GREEN lights remain solid for 50 minutes after brewing is complete. Lights indicate amount of remaining coffee.



 **Warning**

YELLOW - YELLOW lights will appear for 10 minutes after GREEN has elapsed.



 **Expired**

RED - RED lights will flash when coffee expires after 60 minutes. When lights are RED, remove dispenser and discard any remaining coffee.