

Daily Cleaning Instructions





G4GEMXSIFTR10A3026

Single G4GemX 1.5 Gallon Brewer IntelliFresh® and FreshTrac® Technology



McCafé,



1. Remove Dispenser

Take to 3-compartment sink.



3. Remove Brew Basket

Discard paper coffee filter and used grounds.



5. Run a Cleaning Cycle

Use Kay Filter Pouch® Cleaner.



2. Discard Remaining Coffee

Open dispenser faucet and let run until empty.

WARNING - AVOID SCALDING: Liquid inside the dispenser is extremely HOT. Use caution when performing this step.



4. Position Dispenser

Place on brewer. Dispenser lights will flash green.

IMPORTANT - Verify that contact has been made between the dispenser and brewer.



6. Use One (1) Pouch

Place into brew basket. Replace basket into brewer.





When cleaning, use the 3-compartment sink method for washing, rinsing and sanitizing all equipment.



7. Start Cleaning Cycle

Press "REGULAR", then "LARGE BREW". Cleaning will begin immediately.



8. When Brew Cycle is Complete

Discard Kay Filter Pouch, rinse brew basket and allow to air dry.



9. Allow Solution to Sit for 10 Min.

Allow solution to sit in dispenser for 10 minutes, then discard.



10. Discard Cleaning Solution

Dispense through faucet for at least 10 seconds.

WARNING - AVOID SCALDING: Liquid inside the dispenser is extremely HOT. Use caution when performing this step.



11. Discard Remaining Solution

Remove lid and empty dispenser.

WARNING - AVOID SCALDING: Liquid inside the dispenser is extremely HOT. Use caution when performing this step.



12. Rinse the Dispenser

WARNING - DO NOT immerser dispenser in water. DO NOT place dispenser in dishwasher.





When cleaning, use the 3-compartment sink method for washing, rinsing and sanitizing all equipment.



13. Empty Water

Allow water to flow through faucet for 10 seconds.

WARNING - DO NOT immerser dispenser in water. DO NOT place dispenser in dishwasher.



14. Discard Remaining Water



15. Sanitize Dispenser

Fill dispenser with solution of Kay® SolidSense $^{\text{TM}}$ Sanitizer. Allow to sit for one (1) minute.



16. Discard Sanitizer

Dispense through faucet for at least 10 seconds.



17. Discard Remaining Sanitizer

Allow dispenser to air dry. Do not rinse.



18. Wash

Brew basket and dispenser lid.





When cleaning, use the 3-compartment sink method for washing, rinsing and sanitizing all equipment.



19. Disassemble Faucet

Remove from dispenser, unscrew bonnet and pull apart. Place into detergent solution.

NOTE: Clean bonnet weekly.



21. Sanitize

Fill dispenser with solution of Kay $^{\mathbb{B}}$ SolidSense $^{\mathsf{TM}}$ Sanitizer. Allow to sit for one (1) minute.



23. Reassemble Faucet

Assemble and reattach to dispenser. Hand tighten.



20. Rinse

Place brew basket, dispenser lid, and dispenser faucet parts into clean water.



22. Sanitize

Remove parts from sanitizer. Allow to air dry on cart or clean stainless steel surface. DO NOT RINSE.



24. Lock the Lid

Place lid on the dispenser. Lock in place with a slight turn clockwise.







25. Wipe Down Brewer

Wipe the spray head area and exterior surfaces with a new sanitized towel to remove any debris.

NOTE - Remove and clean spray head as recommended.



You are Now Ready to Brew



26. Position Brew Basket & Dispenser

Place on brewer. Dispenser lights will flash green.

IMPORTANT - Verify that contact has been made between the dispenser and brewer.



